


Adobe Photoshop’s color space needs to be set to the working space in which the Sublimation ICC Profile was created. This then allows for a more accurate screen display of your images. The accuracy of the displayed image on your monitor will be highly dependent on the quality of your monitor and, more importantly, a calibrated monitor ICC profile.

Start Photoshop CS4 and bring up the color settings window by clicking *Edit > Color Settings*.

- 1 Set the *Working Spaces—RGB*: to *Adobe RGB (1998)*.
- 2 Set the *Color Management Policies – RGB* to *Convert to Working Space*.

Leave the other settings as shown at right. Click **Save**, then name the settings appropriately.

Photoshop’s RGB working space is now set.




When opening images in Photoshop CS4, you may encounter an **Embedded Profile Mismatch** warning.

- 1 When this **Embedded Profile Mismatch** dialog appears, select *Convert document’s colors to the working space*, then click **OK**.

You can now work on your images as you normally do.

When your image is ready to print, click **File > Print with Preview**.



EPSON R1900 - ICC PROFILES - MAC OS - CS4 PHOTOSHOP

- 1 Select the **Printer** from the drop-down menu.
- 2 Select the **Color Management** option from the drop-down menu.
- 3 Under **Print** choices, check **Document**.
- 4 Under **Color Handling**, select **Photoshop Manages Colors** from the menu.
- 5 Under **Printer Profile**, select the appropriate ICC Profile from the menu.
- 6 Under **Rendering Intent**, select **Perceptual**.
- 7 Click **Print**.

Note: If you do not see any reference to **Sublimation ICC Profile** in the print space list, this means that either the ICC profile is not installed in your system, or **Photoshop** has not been restarted since the profile was installed. This installation requires that **Photoshop** be restarted.

Once you have clicked **Print**, the **Print** window will open.

- 1 Select the **Printer** from the drop-down menu.
- 2 Select **Printer Settings** from the drop-down menu.
- 3 Select **Epson Matte** from the **Media Type** drop-down menu.
- 4 Select **Off (No Color Adjustment)** from the **Color Settings** drop-down menu.
- 5 Select **Photo** from **Print Quality** drop-down menu.
- 6 Check **High Speed** and **Mirror Image**.
- 7 Click **Print**.

Click **Print** in the **Print** dialog, and the image will be sent to the printer with the configured settings.

