


Adobe Photoshop's color space needs to be set to the working space in which the Sublimation ICC Profile was created. This then allows for a more accurate screen display of your images. The accuracy of the displayed image on your monitor will be highly dependent on the quality of your monitor and, more importantly, a calibrated monitor ICC profile.

Start **Photoshop CS** and bring up the color settings window by clicking **Edit > Color Settings**.

- 1 Set the **Working Spaces—RGB**: to **Adobe RGB (1998)**.
- 2 Set the **Color Management Policies – RGB** to **Convert to Working Space**.

Leave the other settings as shown at right. Click **Save**, then name the settings appropriately.

**Photoshop's RGB** working space is now set.




When opening images in **Photoshop CS**, you may encounter an **Embedded Profile Mismatch** warning.

- 1 When this **Embedded Profile Mismatch** dialog appears, select **Convert document's colors to the working space**. Then click **OK**.

You can now work on your images as you normally do.

When your image is ready to print, click **File > Print with Preview**.



# EPSON 4880 - ICC PROFILES - MAC OS - CS PHOTOSHOP

- 1 Select the **Color Management** option from the drop-down menu.
- 2 Under **Source Space**, check **Document**.
- 3 In **Print Space** > **Profile**, select the appropriate profile from the drop-down menu.
- 4 Under **Print Space** > **Intent**, select **Perceptual**.
- 5 Click **Print**.

**Note:** If you do not see any reference to **Sublimation ICC Profile** in the print space list, this means that either the ICC profile is not installed in your system, or **Photoshop** has not been restarted since the profile was installed. This installation requires that **Photoshop** be restarted.

Once you have clicked **Print**, the **Print** window will open.

- 1 Select the Printer from the drop-down menu.
- 2 Select **Printer Settings** from the drop-down menu.
- 3 Select **Plain Paper** from the **Media Type** drop-down menu.
- 4 Select **Off (No Color Adjustment)** from the **Color Settings** drop-down menu.
- 5 Select **Fine — 720 dpi** from **Print Quality** drop-down menu.
- 6 Check **High Speed, Flip Horizontal** and **Finest Detail**.
- 7 Click **Print**.

Click **Print** in the **Print** dialog, and the image will be sent to the printer with the configured settings.

